

BALANCE

**COVERED ROUND
CASSEROLE**

3950512

Outside dimension

30,20 x 27,50 x 12,60 cm (12 x 10 3/4 x 5")

Inside dimension

24,20 x 24,50 x 11,50 cm (9 1/2 x 9 3/4 x 4 1/2")

4,50 L (4.80 qt)

**COVERED ROUND
CASSEROLE**

3950511

Outside dimension

30,80 x 27,30 x 7,70 cm

Inside dimension

24,50 x 24,30 x 6,80 cm (9 3/4 x 9 3/4 x 2 3/4")

2,30 L (2.43 qt)

**RECTANGULAR BAKING DISH**

3950507

Outside dimension

26,30 x 19,10 x 7,70 cm (10 1/4 x 7 3/4 x 3")

Inside dimension

20,30 x 16,50 x 6,00 cm (8 x 6 1/2 x 2 1/4")

1,20 L (1.27 qt)

**RECTANGULAR BAKING DISH**

3950508

Outside dimension

34,00 x 23,60 x 7,80 cm (13 1/2 x 9 1/4 x 2 3/4")

Inside dimension

28,00 x 21,00 x 6,80 cm (11 x 8 1/4 x 2 3/4")

2,40 L (2.54 qt)

**MIXING BOWL**

3950501

Outside dimension

23,80 x 20,40 x 13,70 cm (9 1/4 x 8 x 5 1/2")

Inside dimension

20,00 x 18,30 x 12,00 cm (8 x 7 1/4 x 4 3/4")

2,20 L (2.32 qt)

**RIBBED PIZZA TRAY**

3950504

Outside dimension

39,50 x 35,20 x 3,70 cm (15 1/2 x 13 3/4 x 1 1/2")

Inside dimension

33,80 x 33,00 x 2,50 cm (13 1/4 x 13 x 1")

**RECTANGULAR BAKING DISH**

3950509

Outside dimension

41,70 x 27,80 x 8,40 cm (16 1/2 x 11 x 3 1/4")

Inside dimension

35,50 x 25,00 x 7,30 cm (14 x 9 3/4 x 2 3/4")

4,20 L (4.44 qt)

**3-PC RECTANGULAR BAKING DISH**

3950510

Rectangular baking dish

26,30 x 19,10 x 7,70 cm (10 1/4 x 7 3/4 x 3")

1,20 L (1.27 qt)

Rectangular baking dish

34,00 x 23,60 x 7,80 cm (13 1/2 x 9 1/4 x 2 3/4")

2,40 L (2.54 qt)

Rectangular baking dish

41,70 x 27,80 x 8,40 cm (16 1/2 x 11 x 3 1/4")

4,20 L (4.44 qt)



Material: Body: non-porous ceramic



Material: Body: non-porous ceramic